

# HERO3<sup>+</sup>

BLACK EDITION

## / Hello

Congratulations on your new HERO3+. This Quick Start Guide will help you learn the basics of capturing life's most incredible moments with your GoPro.

### JOIN THE GOPRO MOVEMENT



[facebook.com/GoPro](https://facebook.com/GoPro)



[youtube.com/GoPro](https://youtube.com/GoPro)



[twitter.com/GoPro](https://twitter.com/GoPro)





[instagram.com/GoPro](https://instagram.com/GoPro)

# / Getting Started

**1**


**REMOVE CAMERA FROM HOUSING**



**2**

**REMOVE CAMERA  
SIDE DOOR AND  
INSERT MICROSD  
CARD**

*(Class 10 required, sold separately)*



**3**

**REMOVE CAMERA  
BACK DOOR AND  
INSERT BATTERY**

**4**

**CHARGE BATTERY  
USING INCLUDED  
USB CABLE**

## / Camera Essentials

Shutter/Select Button [  ]

Camera Status Light [red]


LCD Status Screen

Power/Mode Button [  ]

Wi-Fi On/Off Button [  ]

Wi-Fi Status Light [blue]

Camera Status Light [red]




### POWERING CAMERA ON AND OFF


To power **ON**

Press the Power/Mode Button [  ].

To power **OFF**

Press and hold the Power/Mode Button [  ] for two seconds.

## / Selecting Camera Modes

Turn camera **ON** and repeatedly press the Power/Mode Button [  ]

# / Camera Settings\*

## TO ADJUST CAMERA SETTINGS:

1. Press the Power/Mode Button [  ]



### MAIN CAMERA MODES



### CAMERA SETTINGS




### CAPTURE SETTINGS





### SET UP



## / Capturing Video + Photos



Press the Shutter/Select Button [  ] to start/stop recording or take a photo.

You can change video and photo settings in the Settings menu [  ].

# / Default Video + Photo Settings

## DEFAULT VIDEO SETTING: 1080P SUPERVIEW 30 FPS




SuperView delivers the world's most immersive wide angle video, making it easier than ever to capture the shot.

# SUPER VIEW


If you want to experiment with other video settings, you can find more info in the Camera Settings section of the User Manual.

---

## DEFAULT PHOTO SETTING: 12MP



Your camera is set to 12MP resolution, allowing you to capture stunning high-resolution photos.

You can adjust photo resolution in the Settings menu [  ].












# / Pairing Camera to Wi-Fi Remote

Before using the Wi-Fi Remote for the first time, you must pair it with your camera.






## A. ON THE CAMERA:

---

1. Ensure both camera and remote are powered **OFF**.
2. Press the Power/Mode Button [  ] to power camera **ON**.
3. Press the Wi-Fi On/Off Button [  ] twice, then press the Shutter/Select Button [  ] to enter the **Wi-Fi** menu [  ].
4. Press the Power/Mode Button [  ] to cycle to **Wi-Fi RC**, then press the Shutter/Select Button [  ] to select it.
5. Press the Power/Mode Button [  ] to cycle to **NEW**, then press the Shutter/Select Button [  ] to select it. You will see [  ].





## B. ON THE WI-FI REMOTE:

---



1. While holding down the Shutter/Select Button [  ], press and release the Power/Mode Button [  ].
2. When you see [  ], release the Shutter/Select Button [  ].
3. [  ] will appear once camera and remote have paired.
4. The remote will now prompt **CONNECT ANOTHER?** camera. If you want to connect additional cameras at this time, press the Shutter/Select Button [  ] to select **YES**. If not, press the Power/Mode Button [  ] to cycle to **NO**, then press the Shutter/Select Button [  ] to select it.

# / Connecting to the GoPro App

The GoPro App lets you control your camera remotely using a smartphone or tablet. Features include full camera control, live preview, playback and sharing of select content and more\*.

1. Download the GoPro App to your smartphone or tablet at the Apple App Store, Google Play or Windows Phone marketplace.
2. Press the Power/Mode Button [  ] to power camera **ON**.
3. Press the Wi-Fi On/Off Button [  ] twice, then press the Shutter/Select Button [  ] to enter the **Wi-Fi** menu [  ].



4. Press the Power/Mode Button [  ] to cycle to **GoPro App**, then press the Shutter/Select Button [  ] to select it.
5. In your smartphone or tablet's Wi-Fi settings, connect to the network called "GOPRO-BP" followed by a series of numbers/ letters. Enter the password "goprohero"\*\*.
6. Open the GoPro App on your smartphone or tablet.

*\*For device compatibility, please visit [gopro.com](http://gopro.com).*

*\*\*This is the default network name and password. You can customize this if you update your camera software at [gopro.com/update](http://gopro.com/update).*

## / Playing Back Videos and Photos

There are several ways to play back your videos and view your photos.



### **LCD TOUCH BACPAC™**

Removable LCD touch screen  
(sold separately).



### **TV**

Connect via Micro HDMI, Composite  
or Combo Cable (sold separately).



### **GOPRO APP**

Play back and share select content  
using your smartphone or tablet.



### **COMPUTER**


Connect via included USB cable.

# / Mounting Your Camera

**FLAT SURFACE MOUNTING\***

**CURVED SURFACE MOUNTING\***


**VERTICAL MOUNTING**



## / Mounting Your Camera (Continued)

### SIDE MOUNTING


---



### SURFBOARD MOUNTS

---

Included with HERO3+ Black Edition/Surf only.



**NOTE:** To remove adhesive mounts, heat with a hair dryer then peel off mount.

# / Help + Resources

## **CUSTOMER SUPPORT**

GoPro is dedicated to providing the best possible service. To reach GoPro Customer Support, visit [\*\*gopro.com/support\*\*](https://gopro.com/support).

## **GOPRO TUTORIAL VIDEOS**

How-to tutorials, pro tips and tricks to help you make the most of your GoPro products. Visit [\*\*youtube.com/goprotutorials\*\*](https://youtube.com/goprotutorials).

## **CAMERA SOFTWARE UPDATES**

To get the latest features and best performance from your HERO3+, make sure you're using the most current camera software. To check for available updates and download the latest camera software, visit [\*\*gopro.com/update\*\*](https://gopro.com/update).