

**VARIZOOM LANC CONTROLS ARE COMPATIBLE W/ FOLLOWING CAMCORDERS**

<u>Sony Camcorders</u>				<u>Canon camcorders</u>
CCD-TR3000	CCD-TRV81	DCR-TRV525	Sony - need VZ-AV/LANC adapter	XH A1
CCD-TR514	CCD-TRV82	DCR-TRV6	DCR-DVD610	XH A1S
CCD-TR516	CCD-TRV85	DCR-TRV70	DCR-DVD650	XH G1
CCD-TR54	CCD-TRV90	DCR-TRV730	DCR-DVD710	XH G1S
CCD-TR64	CCD-TRV91	DCR-TRV740	DCR-DVD810	XL H1*
CCD-TR716	CCD-TRV95	DCR-TRV80	DCR-DVD850	XL H1A*
CCD-TR74	CCD-TRV99	DCR-TRV820	DCR-DVD910	XL H1S*
CCD-TR814	DCR-DVD100	DCR-TRV830	DCR-HC52	XL1*
CCD-TR84	DCR-DVD201	DCR-TRV9	DCR-SR220	XL1S*
CCD-TR87	DCR-DVD508	DCR-TRV900	DCR-SR220D	XL2*, **
CCD-TR88	DCR-HC42	DCR-TRV950	DCR-SR45	XL2 Body Kit*, **
CCD-TR88	DCR-IP55	DCR-VX1000	DCR-SR47	Elura
CCD-TR910	DCR-PC1	DCR-VX2000	DCR-SR65	Elura 10
CCD-TR916	DCR-PC100	DCR-VX2100	DCR-SR67	Elura 2
CCD-TR917	DCR-PC101	DCR-VX700	DCR-SR85	Elura 20MC
CCD-TR96	DCR-PC120	DSR-200	DCR-SR87	Elura 2MC
CCD-TR98	DCR-PC5	DSR-250	DCR-SX40	Elura 40MC
CCD-TR99	DCR-PC7	DSR-PD100(A)	DCR-SX41	Elura 50
CCD-TRV119	DCR-SR200	DSR-PD150	DCR-SX60	GL1
CCD-TRV15	DCR-SR300	DSR-PD170	HDR-CX100	GL2
CCD-TRV19	DCR-TR7000	DSR-PDX10	HDR-CX500V	Optura
CCD-TRV20	DCR-TRV10	HCR-SR5C	HDR-CX520V	Optura 100MC
CCD-TRV21	DCR-TRV110	HDR-FX1	HDR-SR10	Optura 200MC
CCD-TRV215	DCR-TRV110	HDR-FX1000	HDR-SR11	Optura Pi
CCD-TRV25	DCR-TRV120	HDR-FX7	HDR-SR12	Ultura
CCD-TRV25	DCR-TRV19	HDR-HC1	HDR-TG1	Vistura
CCD-TRV29	DCR-TRV20	HDR-HC7	HDR-TG5V	ZR
CCD-TRV32	DCR-TRV210	HDR-SR5	HDR-UX10	ZR10
CCD-TRV33	DCR-TRV22	HDR-SR7	HDR-XR100	ZR20
CCD-TRV350	DCR-TRV240	HDR-SR8	HDR-XR200V	ZR25MC
CCD-TRV39	DCR-TRV25	HDR-UX5	HDR-XR500V	ZR30MC
CCD-TRV40	DCR-TRV27	HVR-A1U	HDR-XR520V	ZR40
CCD-TRV43	DCR-TRV30	HVR-HD1000U		ZR45MC
CCD-TRV51	DCR-TRV310	HVR-V1U		ZR50MC
CCD-TRV615	DCR-TRV340	HVR-Z1U		
CCD-TRV62	DCR-TRV39	HVR-Z5U		*'A' button n/a
CCD-TRV65	DCR-TRV5	HVR-Z7U		
CCD-TRV715	DCR-TRV510	HVR-S270U		**Rock MF n/a for XL2
CCD-TRV75	DCR-TRV520	HXR-NX5U		